



# Orbit Instillation for Audi TT

## ASHTRAY REMOVAL

1. Open the ashtray
2. Remove the screw in the middle of the ashtray
3. Pull out the ashtray and unplug the 2 sockets above the ashtray

## CENTER TRAY REMOVAL

1. Slide open the center tray
2. Pull up the switch console **Fig.1**
3. Use a screwdriver to lift up the center tray **Fig.2 Fig.3**

## FACTORY SHIFT KNOB REMOVAL

Twist off the factory knob counter-clockwise and pull it out from the shift rod

## ORBIT KNOB INSTALL & WIRING

1. Remove the factory Detach surround and trim
2. Remove the plastic spring (locate at the bottom of the shift rod), and cut a gap on the plastic spring **Fig.8**
3. Thread the wires of the Orbit knob through the shift rod
4. Place the plastic spring back on-to the shift rod **Fig.9**
5. Route the wire through the shift lever trim housing to the center tray area, and go all the way to the back of the footwell **Fig.5 Fig.6**
6. Use supplied wire clips to clip the wires onto the socket of the ashtray **Fig.7**

## ORBIT RING INSTALL & WIRING

1. Remove the factory Detach surround and trim
2. Place the Orbit Ring onto the shift lever trim housing (with wires opened gaps side face down)
3. Route the wire through the shift lever trim housing to the center tray area, and go all the way to the back of the footwell **Fig.5 Fig.6**
4. Use supplied wire clips to clip the wires onto the socket of the ashtray **Fig.7**
5. Place the Detach surround and trim on top the Orbit Ring and use supplied screws to tighten up

